

LE-UVWE5D

PRODUCT INFORMATION



ASSEMBLY

LE-UVWE5D package includes the following items:

- LE-UVWE5D unit
- Heavy Duty Mounting Clamp
- Power Supply
- LE-UVWE5D manual

Mounting LE-UVWE5D Magnifying Lamp

1. Attach the mounting clamp to the side of your work bench and hand tighten
2. Then insert LE-UVWE5D lamp into the hole of the mounting table clamp

Magnification	2.25X (5-Diopter)
Lens Dimension	19 x 15,7 mm (7.5" x 6.2")
Color	Black
Lighting	48 White LEDs (6500K) 30 UV LEDs (365nm)
Lumen	Max: 1100Lm
ESD safe	Yes
Plug Type	Type F (Schuko)
INPUT	100-240V~ 50/60Hz 0.3AMax

HOW TO USE



Using Your LE-UVWE5D Magnifying Lamp

1. Connect LE-UVWE5D to a power outlet
2. Turn the power ON/OFF by pressing the Power Switch
3. Select White LEDs or UV LEDs
4. Adjust the brightness with the LED Brightness Control (works with White LEDs only)



Adjusting Arm Position

1. Loosen the Adjustable Tension Knob
2. Set the desired position and lamp head angle, and re-tighten

PRODUCT MAINTENANCE:

ESD paint was not designed to be cleaned with alcohol-based cleaners. Damages of the ESD safe properties of the paint and removing some of the paint will occurs.
Paint should only be cleaned with a soft cotton cloth.

This product contains a light source of energy efficiency **class F**.



WARNING: UV RADIATION HAZARD

**THIS LAMP EMITS UVA RADIATION (365 NM).
PROLONGED EXPOSURE MAY CAUSE EYE AND SKIN INJURY.**

TO REDUCE RISK:

- WEAR **UV-RATED PROTECTIVE EYEWEAR AND GLOVES.**
- **AVOID DIRECT EYE EXPOSURE** TO UV LIGHT.
- **MAINTAIN A SAFE DISTANCE AND LIMIT EXPOSURE TIME.**
- USE **PROTECTIVE BARRIERS** WHERE FEASIBLE.

FAILURE TO FOLLOW THESE PRECAUTIONS MAY RESULT IN INJURY.