

LE-WWE5D

PRODUCT INFORMATION

Magnification	2.25X (5-Diopter)
Lens Dimension	7.5" x 6.2"
Color	Black
Lighting	30 LEDs (3500K) 30 LEDs (6500K) 1-10W Adjustable Brightness
ESD safe	Yes
Plug Type	Type F (Schuko)
INPUT	100-240V~ 50/60Hz 0.3A Max



ASSEMBLY

LE-WWE5D package includes the following items:

- LE-WWE5D unit
- Heavy Duty Mounting Clamp
- Power Supply
- LE-WWE5D manual

Mounting LE-WWE5D Magnifying Lamp

1. Attach the mounting clamp to the side of your work bench and hand tighten
2. Then insert LE-WWE5D lamp into the hole of the mounting table clamp



HOW TO USE

Using Your LE-WWE5D Magnifying Lamp

1. Connect LE-WWE5D to a power outlet
2. Turn the power ON/OFF by pressing the Power Switch
3. Adjust the brightness of the white LEDs with the White LED Controls
4. Adjust the brightness of the amber LEDs with the Amber LED Controls

Adjusting Arm Position

1. Loosen the Adjustable Tension Knob
2. Set the desired position and lamp head angle, and re-tighten

PRODUCT MAINTENANCE:

ESD paint was not designed to be cleaned with alcohol-based cleaners. Damages of the ESD safe properties of the paint and removing some of the paint will occurs. **Paint should only be cleaned with a soft cotton cloth.**

This product contains a light source of energy efficiency **class F**.