

LE-HDWWE5D

ESD Safe Magnifying Lamp with Built-in Tilt Camera



The LE-HDWWE5D combines a magnifying lamp with a camera inspection system, enabling direct image viewing on an HDMI monitor and image/video capture on the provided microSD Card.



RE-IMAGINE YOUR
MAGNIFYING LAMP



Built-in Camera

**INSPECT THROUGH A MONITOR AND
MAGNIFYING LENS**

Its innovative feature allows team members to simultaneously observe subjects under the magnification lens in real-time while the user conducts an inspection through the lens.



KEY FEATURES

Ideal-tek's High-Definition Camera Magnifying Lamp, the newest addition to our visual inspection systems, retains the beloved features of previous models and incorporates a high-quality camera. This all-in-one unit enables direct HDMI monitor viewing, captures images/videos on a microSD Card, and supports PC connectivity for viewing and managing files.

- HDMI Output - connect to you HD monitor
- USB-C Output - Connect the camera to your PC
- Crystal-clear 5-diopter glass lens (2.25x)
- View/Save Images on a micro SD card
- Inspect objects through the magnifying lens & on an HD monitor simultaneously
- ESD Safe - Dissipates electrostatic discharge
- Frosted LED diffuser for uniform light spread
- 60 LEDs with adjustable color temperature
- Fully covered spring balanced arm, max reach 36 inches (914 mm)
- Included IR remote to control on-screen functions



LE-HDWWE5D 5 Diopter ESD Safe

Magnification	5 Diopter (2.25x)
ESD safe	Yes
Lens Dimension	7.5" x 6.2"
Camera	1080p HD 30FPS
Reach	Up to 36" (914 mm)
Illumination	30 High Intensity 6500K (Cool) LEDs 30 High Intensity 3500K (Warm) LEDs
MicroSD Capacity	16 GB
Output	HDMI USB-C MicroSD
Plug Type	Type F (Schuko)

This product contains a light source of energy efficiency class F.

Built-in Camera	USB-C Output	5 Diopter Lens	Micro SD CARD
On-screen Viewing	Connect to your PC	2.25x Magnification	Save and view Images / Videos

