

Product Datasheet

Product code: **380.BB.W**

Product type: Multi-purpose Scissors

Made in: Taiwan

Description: The 380 are Multi-Purpose shears with strong blades, ideal for heavy-duty cuts. The sharp blades guarantee a precise and clean cuts. The serrated blade allows non-slip cutting. The Polypropylene/Thermoplastic rubber handles provides the scissors with an ergonomic handle suitable for comfortable multiple Heavy-duty cuts. The Inox material is suitable for cleaning. The blades are hardened to 54HRC hardness.

Tip description: straight, sharp, strong, sawtoothed

Coating/finishing: Sandpaper

Body material: Stainless Steel (Hardened AISI 420)

Handle material: Polypropylene (PP) and Thermoplastic Rubber (TPR)

Picture:



Product dimensions:

OAL	145.0 mm – 5.709 inch
Width	45.0 mm – 1.772 inch
Height	14.5 mm – 0.571 inch

Tip dimensions:

Tip width	2.00 mm – 0.079 inch
Tip thickness	2.10 mm – 0.083 inch