

## Product Datasheet

**Product code:** **ES5350.CR.BG**

**Product type:** High Precision Cutters

**Made in:** Italy

**Description:** The 5350 is a high precision cutter belonging to the large tapered cutter family. This type of geometry and head dimensions offer an advantage to support the cut. The semi-flush cutting edge is suitable to perform robust cuts. The 5350 is equipped with an ESD Ergo-tek slim handle which allows an excellent grip, suitable to environments and to components susceptible to electrostatic discharge. The blades are hardened to 67HRC hardness.

**Head description:** Large, Tapered

**Cutting edges:** Semi-Flush

**Cutting capacity:** soft wire 0.30-1.60 mm (29-14 AWG)

**Body material:** High carbon-chromium low alloy steel (100Cr6)

**Body finishing:** Sandblasted

**Handle material:** Ergo-tek Slim - Thermoplastic Elastomer + PP compound

**Picture:**



**Dimensions:** OAL (A) 125.0 mm – 4.921 inch  
Width 60.0 mm – 2.362 inch  
Height 18.0 mm – 0.709 inch

**Head dimensions:** Width (C) 12.0 mm – 0.472 inch  
Thickness (D) 6.4 mm – 0.252 inch  
B 12.0 mm – 0.472 inch  
F 0.2 mm – 0.008 inch

