

Product Datasheet

Product code: **WS3620**

Product type: Wire Stripper

Made in: Germany

Description: The WS3620 wire stripper is a fast and safe stripping tool for the finest, most flexible conductors, strands and wires with small diameters (from 0.12 to 0.8 mm). Most common applications include: industrial, electronics, computer and network technology, telecommunications or modelling. The scanning system of the semi-automatic stripping pliers moves automatically to the respective conductor cross-section so that cutting depth setting is no longer required. With the adjustable scaled length stop, the desired stripping length can be reliably adjusted. Two torsion springs act symmetrically with a defined force to the blades and cut the respective insulation with appropriate pressure. This, in conjunction with the integrated scanning system, results in damage-free stripping.

Picture:



Product dimensions:	OAL	112.0 mm – 4.409 inch
	Width	57.0 mm – 2.244 inch
	Height	18.0 mm – 0.709 inch