

Product Datasheet

Product code: **XXL1.S.0**

Product type: Diamond Tweezers

Made in: Switzerland

Description: Type XXL1 Diamond tweezers are suitable to jewellery applications which require holding a diamond very firmly. The line serration provides the handles with extra grip and the rhomb serrated tips with groove prevent any possible slips. It is also equipped with very hard, stiff tips and body to prevent it from bending.

Tip description: straight, extra extra large, beveled, strong, rhomb serrated with lengthwise groove, superior finish

Coating/finishing: Sandblasted

Body material: Stainless Steel (S)

Picture:




Tweezer dimensions:

OAL	160.0 mm – 6.299 inch
Width	9.0 mm – 0.354 inch
Height	12.5 mm – 0.492 inch

Tip details:



Dimensions mm



Dimensions inch



Tip dimensions:

Tip width	2.40 mm – 0.094 inch
Tip thickness	0.90 mm – 0.035 inch